

| Make         | Model                              | Displacement | Year | Country | Engine       | Info                          | Position        |
|--------------|------------------------------------|--------------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | COMMANDER 1000 EFI                 | 1000         | 2011 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI                 | 1000         | 2012 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI                 | 1000         | 2013 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI                 | 1000         | 2014 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI DPS             | 1000         | 2013 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI DPS             | 1000         | 2014 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI DPS             | 1000         | 2015 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI DPS             | 1000         | 2016 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI DPS             | 1000         | 2017 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Limited         | 1000         | 2012 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Limited DPS     | 1000         | 2013 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Limited DPS     | 1000         | 2014 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Limited DPS     | 1000         | 2015 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Limited DPS     | 1000         | 2016 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Limited DPS     | 1000         | 2017 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max DPS         | 1000         | 2014 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max DPS         | 1000         | 2015 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max Limited DPS | 1000         | 2015 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max DPS         | 1000         | 2016 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                    |      |      |          |              |                               |                 |
|--------------|------------------------------------|------|------|----------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | COMMANDER 1000 EFI Max Limited DPS | 1000 | 2016 | AMER-ICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max DPS         | 1000 | 2017 | AMER-ICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max Limited DPS | 1000 | 2017 | AMER-ICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI X               | 1000 | 2011 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI X               | 1000 | 2012 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI X DPS           | 1000 | 2013 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT              | 1000 | 2011 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT              | 1000 | 2012 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT DPS          | 1000 | 2013 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT DPS          | 1000 | 2014 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT-P DPS        | 1000 | 2014 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max XT DPS      | 1000 | 2014 | AMER-ICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT DPS          | 1000 | 2015 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT-P DPS        | 1000 | 2015 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max XT DPS      | 1000 | 2015 | AMER-ICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT DPS          | 1000 | 2016 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT-P DPS        | 1000 | 2016 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI Max XT DPS      | 1000 | 2016 | AMER-ICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT DPS          | 1000 | 2017 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 EFI XT-P DPS        | 1000 | 2017 | ALL      | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |   |      |      |         |              |                               |                 |
|--------------|---|------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | COMMANDER 1000 EFI Max XT DPS                   | 1000 | 2017 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4                               | 976  | 2016 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4                               | 976  | 2017 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4                               | 976  | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 DPS                           | 976  | 2016 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 DPS                           | 976  | 2017 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 DPS                           | 976  | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 DPS                           | 976  | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max DPS                       | 976  | 2017 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max DPS                       | 976  | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max DPS                       | 976  | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Mossy Oak Hunting Edition DPS | 976  | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Mossy Oak Hunting Edition DPS | 976  | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max Lone Star DPS             | 976  | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max Lone Star DPS             | 976  | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max X MR DPS                  | 976  | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 X MR DPS                      | 976  | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max X MR DPS                  | 976  | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS                        | 976  | 2016 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS CAB                    | 976  | 2016 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                  |     |      |         |              |                               |                 |
|--------------|----------------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | DEFENDER HD10 4X4 Max XT DPS     | 976 | 2017 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS         | 976 | 2017 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS CAB     | 976 | 2017 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS         | 976 | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS CAB     | 976 | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT-P DPS       | 976 | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max XT DPS     | 976 | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max XT DPS CAB | 976 | 2018 | ALL     | 54 KW(73 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS         | 976 | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT DPS CAB     | 976 | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 XT-P DPS       | 976 | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max XT DPS     | 976 | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD10 4X4 Max XT DPS CAB | 976 | 2019 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD5 4X4                 | 427 | 2018 | ALL     | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD5 4X4                 | 427 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD5 4X4 DPS             | 427 | 2018 | ALL     | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD5 4X4 DPS             | 427 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4                 | 800 | 2016 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4                 | 800 | 2017 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4                 | 800 | 2018 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                |     |      |         |              |                               |                 |
|--------------|--------------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | DEFENDER HD8 4X4               | 800 | 2019 | AMERICA | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 DPS           | 800 | 2016 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 DPS           | 800 | 2017 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 DPS           | 800 | 2018 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 DPS           | 800 | 2019 | AMERICA | 37 KW(50 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max DPS       | 800 | 2017 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max           | 800 | 2018 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max DPS       | 800 | 2018 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max           | 800 | 2019 | AMERICA | 37 KW(50 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max DPS       | 800 | 2019 | AMERICA | 37 KW(50 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 XT DPS        | 800 | 2016 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max XT DPS    | 800 | 2017 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 XT DPS        | 800 | 2017 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 XT DPS        | 800 | 2018 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 XT DPS CAB    | 800 | 2018 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max XT DPS    | 800 | 2018 | ALL     | 38 KW(51 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 XT DPS        | 800 | 2019 | AMERICA | 37 KW(50 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 XT DPS CAB    | 800 | 2019 | AMERICA | 37 KW(50 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | DEFENDER HD8 4X4 Max XT DPS    | 800 | 2019 | AMERICA | 37 KW(50 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 900 HO EFI 4X4 X3 DPS | 900 | 2018 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                          |     |      |     |  |                               |                 |
|--------------|--------------------------|-----|------|-----|--|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 330 HO 2x4     | 330 | 2003 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 330 HO 4X4     | 330 | 2003 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 2x4     | 400 | 2003 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4     | 400 | 2003 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 330 HO 2x4     | 330 | 2004 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 330 HO 4X4     | 330 | 2004 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 2x4     | 400 | 2004 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4     | 400 | 2004 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 330 HO 2x4     | 330 | 2005 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 330 HO 4X4     | 330 | 2005 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4     | 400 | 2005 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4     | 400 | 2006 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 | 650 | 2006 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 | 800 | 2006 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4     | 400 | 2007 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 | 500 | 2007 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 | 650 | 2007 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 | 800 | 2007 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4     | 400 | 2008 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI HO 4X4 | 400 | 2008 | ALL |  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                          |      |      |         |                            |                               |                 |
|--------------|--------------------------|------|------|---------|----------------------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 | 500  | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 | 650  | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 | 800  | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4    | 400  | 2009 | ALL     | 23 KW(31 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4    | 500  | 2009 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4    | 400  | 2010 | ALL     | 23 KW(31 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4    | 500  | 2010 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4    | 400  | 2011 | ALL     | 24 KW(33 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4    | 500  | 2011 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4    | 650  | 2011 | ALL     | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4    | 500  | 2012 | ALL     | 15 KW(20 PS); 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4    | 400  | 2012 | ALL     | 15 KW(20 PS); 24 KW(33 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4   | 1000 | 2012 | AMERICA | 61 KW(83 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4    | 650  | 2012 | AMERICA | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4    | 400  | 2013 | ALL     | 24 KW(32,5 PS)             | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4    | 500  | 2013 | ALL     | 35 KW(47 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4   | 1000 | 2013 | AMERICA | 61 KW(83 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4    | 650  | 2013 | AMERICA | 46 KW(63 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4    | 400  | 2014 | ALL     | 24 KW(32,5 PS)             | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4    | 500  | 2014 | ALL     | 35 KW(47 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                           |     |      |         |              |                               |                 |
|--------------|---------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4     | 650 | 2014 | AMERICA | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4   | 450 | 2015 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 500 EFI 4X4   | 500 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4     | 650 | 2015 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4   | 450 | 2016 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 570 EFI 4X4   | 570 | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4     | 650 | 2016 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4     | 450 | 2017 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4     | 570 | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4     | 650 | 2017 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4     | 450 | 2018 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4     | 570 | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4     | 650 | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4     | 427 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4     | 570 | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4     | 650 | 2019 | AMERICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4     | 854 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4     | 427 | 2020 | ALL     | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4     | 570 | 2020 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 DPS | 500 | 2013 | ALL     | 35 KW(47 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |



|              |                             |      |      |         |              |                               |                 |
|--------------|-----------------------------|------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 DPS  | 1000 | 2013 | AMERICA | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 DPS   | 650  | 2013 | AMERICA | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 DPS   | 500  | 2014 | ALL     | 35 KW(47 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 DPS  | 1000 | 2014 | AMERICA | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 DPS   | 650  | 2014 | AMERICA | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4 DPS | 450  | 2015 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 500 EFI 4X4 DPS | 500  | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 DPS  | 1000 | 2015 | ALL     | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 DPS   | 650  | 2015 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 DPS   | 500  | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4 DPS | 450  | 2016 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 570 EFI 4X4 DPS | 570  | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 DPS   | 570  | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 DPS   | 650  | 2016 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 DPS   | 850  | 2016 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 DPS   | 450  | 2017 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 DPS   | 570  | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 DPS   | 650  | 2017 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 DPS   | 850  | 2017 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 6x6 DPS   | 650  | 2017 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                |     |      |         |              |                               |                 |
|--------------|--------------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 DPS      | 450 | 2018 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 DPS      | 570 | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 DPS      | 650 | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 DPS      | 850 | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 6x6 DPS      | 650 | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 6x6 DPS      | 650 | 2019 | ALL     | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 DPS      | 427 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 DPS      | 570 | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 6x6 DPS      | 450 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 DPS      | 650 | 2019 | AMERICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 DPS      | 854 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 DPS      | 570 | 2020 | ALL     | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 DPS      | 427 | 2020 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 570 EFI 4X4 DPS LE | 570 | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max       | 400 | 2004 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max       | 400 | 2005 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max       | 400 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 Max   | 650 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max   | 800 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max       | 400 | 2007 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                  |     |      |         |                            |                               |                 |
|--------------|----------------------------------|-----|------|---------|----------------------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 Max     | 500 | 2007 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 Max     | 650 | 2007 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max     | 800 | 2007 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max LTD | 800 | 2007 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max         | 400 | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI HO 4X4 Max     | 400 | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 Max     | 500 | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 Max     | 650 | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max     | 800 | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max LTD | 800 | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max        | 400 | 2009 | ALL     | 23 KW(31 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max        | 500 | 2009 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max        | 400 | 2010 | ALL     | 23 KW(31 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max        | 500 | 2010 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max        | 400 | 2011 | ALL     | 24 KW(33 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max        | 500 | 2011 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max        | 650 | 2011 | ALL     | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max        | 400 | 2012 | ALL     | 15 KW(20 PS); 24 KW(33 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max        | 650 | 2012 | AMERICA | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max        | 500 | 2012 | AMERICA | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |  |      |      |         |                |                               |                 |
|--------------|--|------|------|---------|----------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max              | 400  | 2013 | ALL     | 24 KW(32,5 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max Limited DPS | 1000 | 2013 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max              | 650  | 2013 | ALL     | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max              | 500  | 2013 | ALL     | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max DPS          | 500  | 2013 | ALL     | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max DPS         | 1000 | 2013 | AMERICA | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max DPS          | 650  | 2013 | AMERICA | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max              | 400  | 2014 | ALL     | 24 KW(32,5 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max Limited DPS | 1000 | 2014 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max              | 650  | 2014 | ALL     | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max              | 500  | 2014 | ALL     | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max DPS          | 500  | 2014 | ALL     | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max DPS         | 1000 | 2014 | AMERICA | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max DPS          | 650  | 2014 | AMERICA | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4 Max            | 450  | 2015 | ALL     | 29 KW(39 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 500 EFI 4X4 Max            | 500  | 2015 | ALL     |                | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4 Max DPS        | 450  | 2015 | ALL     | 29 KW(39 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 500 EFI 4X4 Max DPS        | 500  | 2015 | ALL     |                | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max DPS         | 1000 | 2015 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max Limited DPS | 1000 | 2015 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                 |     |      |         |              |                               |                 |
|--------------|---------------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max       | 650 | 2015 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max DPS   | 650 | 2015 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max DPS   | 500 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4 Max     | 450 | 2016 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 570 EFI 4X4 Max     | 570 | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 450 EFI 4X4 Max DPS | 450 | 2016 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 570 EFI 4X4 Max DPS | 570 | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max DPS   | 650 | 2016 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max DPS   | 570 | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max       | 450 | 2017 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max DPS   | 450 | 2017 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max       | 570 | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max DPS   | 570 | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max DPS   | 650 | 2017 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max       | 450 | 2018 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max       | 570 | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max DPS   | 450 | 2018 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max DPS   | 570 | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max DPS   | 650 | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max       | 427 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |   |     |      |         |              |                               |                 |
|--------------|---|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max                           | 570 | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max DPS                       | 427 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max DPS                       | 570 | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max DPS                       | 650 | 2019 | AMERICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max DPS                       | 570 | 2020 | ALL     | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max                           | 427 | 2020 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max                           | 570 | 2020 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max DPS                       | 427 | 2020 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 6x6 Max DPS                       | 450 | 2020 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 North Edition                 | 650 | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 North Edition                 | 850 | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max North Edition             | 650 | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max North Edition             | 850 | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 North Edition                 | 650 | 2019 | AMERICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 North Edition                 | 854 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max North Edition             | 650 | 2019 | AMERICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max North Edition             | 854 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Mossy Oak Hunting Edition DPS | 450 | 2018 | ALL     | 29 KW(39 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Mossy Oak Hunting Edition DPS | 570 | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Mossy Oak Hunting Edition DPS | 427 | 2019 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |   |     |      |         |              |                               |                 |
|--------------|---|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Mossy Oak Hunting Edition DPS | 570 | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Mossy Oak Hunting Edition DPS | 427 | 2020 | AMERICA | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Mossy Oak Hunting Edition DPS | 570 | 2020 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 T                             | 427 | 2019 | EUROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 T DPS                         | 427 | 2019 | EUROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 T DPS                         | 570 | 2019 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 PRO T DPS                     | 427 | 2019 | EUROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 PRO T DPS                     | 570 | 2019 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max T DPS                     | 427 | 2019 | EUROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max T DPS                     | 570 | 2019 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max Pro+ T DPS                | 650 | 2019 | EUROPE  | 43 KW(59 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 6x6 T DPS                         | 650 | 2019 | EUROPE  | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 6x6 Pro+ Sidewall T DPS          | 976 | 2019 | EUROPE  | 61 KW(82 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 6x6 Max Pro+ Sidewall T DPS      | 976 | 2019 | EUROPE  | 61 KW(82 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 Max T DPS                     | 427 | 2020 | EUROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max T DPS                     | 570 | 2020 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 PRO T DPS                     | 427 | 2020 | EUROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 PRO T DPS                     | 570 | 2020 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 T                             | 427 | 2020 | EUROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 T                             | 570 | 2020 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                  |      |      |          |              |                               |                 |
|--------------|----------------------------------|------|------|----------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 450 EFI 4X4 T DPS      | 427  | 2020 | EU-ROPE  | 28 KW(38 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 T DPS      | 570  | 2020 | EU-ROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 X MR DPS  | 1000 | 2013 | ALL      | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR       | 650  | 2013 | ALL      | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR DPS   | 650  | 2013 | AMER-ICA | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 X MR DPS  | 1000 | 2014 | ALL      | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR DPS   | 650  | 2014 | AMER-ICA | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 X MR DPS  | 1000 | 2015 | ALL      | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR DPS   | 650  | 2015 | ALL      | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER L 570 EFI 4X4 X MR DPS | 570  | 2016 | ALL      | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR DPS   | 650  | 2016 | ALL      | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 X MR DPS   | 850  | 2016 | ALL      | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 X MR DPS   | 570  | 2017 | ALL      | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR DPS   | 650  | 2017 | ALL      | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 X MR DPS   | 850  | 2017 | ALL      | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 X MR DPS   | 570  | 2018 | ALL      | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR DPS   | 650  | 2018 | ALL      | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 X MR DPS   | 850  | 2018 | ALL      | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 X MR DPS   | 570  | 2019 | AMER-ICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 X MR DPS   | 650  | 2019 | AMER-ICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |



|              |                                   |     |      |         |              |                               |                 |
|--------------|-----------------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 X MR DPS    | 854 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 X MR DPS    | 570 | 2020 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 X XC T DPS | 976 | 2019 | EUROPE  | 61 KW(82 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 XT           | 400 | 2003 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 XT           | 400 | 2004 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max XT       | 400 | 2004 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 XT           | 400 | 2005 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max XT       | 400 | 2005 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 XT           | 400 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max XT       | 400 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 XT       | 650 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 Max XT   | 650 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 XT       | 800 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max XT   | 800 | 2006 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 XT           | 400 | 2007 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max XT       | 400 | 2007 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 XT       | 500 | 2007 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 Max XT   | 500 | 2007 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 XT       | 650 | 2007 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 Max XT   | 650 | 2007 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                 |     |      |     |              |                               |                 |
|--------------|---------------------------------|-----|------|-----|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 XT     | 800 | 2007 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max XT | 800 | 2007 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 XT         | 400 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 HO 4X4 Max XT     | 400 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI HO 4X4 XT     | 400 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI HO 4X4 Max XT | 400 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 XT     | 500 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI HO 4X4 Max XT | 500 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 XT     | 650 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI HO 4X4 Max XT | 650 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 XT     | 800 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 EFI HO 4X4 Max XT | 800 | 2008 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 XT        | 400 | 2009 | ALL | 23 KW(31 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max XT    | 400 | 2009 | ALL | 23 KW(31 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT        | 500 | 2009 | ALL | 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT    | 500 | 2009 | ALL | 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 XT        | 400 | 2010 | ALL | 23 KW(31 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max XT    | 400 | 2010 | ALL | 23 KW(31 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT        | 500 | 2010 | ALL | 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT-P      | 500 | 2010 | ALL | 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                 |      |      |         |                            |                               |                 |
|--------------|---------------------------------|------|------|---------|----------------------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT    | 500  | 2010 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT-P  | 500  | 2010 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max XT    | 400  | 2011 | ALL     | 24 KW(33 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT        | 500  | 2011 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT    | 500  | 2011 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT        | 650  | 2011 | ALL     | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT    | 650  | 2011 | ALL     | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT-P      | 650  | 2011 | AMERICA | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT-P  | 650  | 2011 | AMERICA | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 XT       | 1000 | 2012 | ALL     | 61 KW(83 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT        | 650  | 2012 | ALL     | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT    | 650  | 2012 | ALL     | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT-P  | 650  | 2012 | ALL     | 44 KW(60 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT        | 500  | 2012 | ALL     | 15 KW(20 PS); 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT    | 500  | 2012 | ALL     | 15 KW(20 PS); 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max XT    | 400  | 2012 | ALL     | 15 KW(20 PS); 24 KW(33 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 XT        | 400  | 2012 | AMERICA | 24 KW(33 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max XT    | 400  | 2013 | ALL     | 24 KW(32,5 PS)             | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 XT DPS   | 1000 | 2013 | ALL     | 61 KW(83 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 XT-P DPS | 1000 | 2013 | ALL     | 61 KW(83 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                     |      |      |         |                |                               |                 |
|--------------|-------------------------------------|------|------|---------|----------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max XT-P DPS | 1000 | 2013 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT DPS        | 650  | 2013 | ALL     | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT DPS    | 650  | 2013 | ALL     | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 XT            | 400  | 2013 | AMERICA | 24 KW(32,5 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max XT DPS   | 1000 | 2013 | AMERICA | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT DPS        | 500  | 2013 | AMERICA | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT DPS    | 500  | 2013 | AMERICA | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 Max XT        | 400  | 2014 | ALL     | 24 KW(32,5 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 XT DPS       | 1000 | 2014 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 XT-P DPS     | 1000 | 2014 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max XT-P DPS | 1000 | 2014 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT DPS        | 650  | 2014 | ALL     | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT DPS    | 650  | 2014 | ALL     | 46 KW(63 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 400 EFI 4X4 XT            | 400  | 2014 | AMERICA | 24 KW(32,5 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max XT DPS   | 1000 | 2014 | AMERICA | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT DPS        | 500  | 2014 | AMERICA | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT DPS    | 500  | 2014 | AMERICA | 35 KW(47 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 XT DPS       | 1000 | 2015 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 XT-P DPS     | 1000 | 2015 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max XT DPS   | 1000 | 2015 | ALL     | 61 KW(83 PS)   | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                     |      |      |     |              |                               |                 |
|--------------|-------------------------------------|------|------|-----|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max XT-P DPS | 1000 | 2015 | ALL | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 6x6 XT           | 1000 | 2015 | ALL | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT DPS        | 650  | 2015 | ALL | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT DPS    | 650  | 2015 | ALL | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 6x6 XT DPS        | 650  | 2015 | ALL | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 XT DPS        | 500  | 2015 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 500 EFI 4X4 Max XT DPS    | 500  | 2015 | ALL |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 XT DPS        | 570  | 2016 | ALL | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT DPS        | 650  | 2016 | ALL | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT DPS        | 850  | 2016 | ALL | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT-P DPS      | 850  | 2016 | ALL | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 6x6 XT DPS        | 650  | 2016 | ALL | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 6x6 XT           | 1000 | 2016 | ALL | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max XT DPS    | 570  | 2016 | ALL | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT DPS    | 650  | 2016 | ALL | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max XT DPS    | 850  | 2016 | ALL | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max XT-P DPS  | 850  | 2016 | ALL | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 XT DPS        | 570  | 2017 | ALL | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT DPS        | 650  | 2017 | ALL | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT DPS        | 850  | 2017 | ALL | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                    |      |      |         |              |                               |                 |
|--------------|------------------------------------|------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT-P DPS     | 850  | 2017 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max XT DPS   | 570  | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT DPS   | 650  | 2017 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT-P DPS | 650  | 2017 | ALL     | 44 KW(60 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max XT DPS   | 850  | 2017 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max XT-P DPS | 850  | 2017 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 6x6 XT DPS       | 650  | 2017 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 6x6 XT          | 1000 | 2017 | ALL     | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 XT DPS       | 570  | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max XT DPS   | 570  | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT DPS       | 650  | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT DPS       | 850  | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT DPS   | 650  | 2018 | ALL     | 46 KW(63 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max XT DPS   | 850  | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT-P DPS     | 850  | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 6x6 XT DPS      | 1000 | 2018 | ALL     | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 XT DPS       | 570  | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max XT DPS   | 570  | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 XT DPS       | 650  | 2019 | AMERICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT DPS       | 854  | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                       |     |      |         |              |                               |                 |
|--------------|---------------------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 XT-P DPS        | 850 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT DPS      | 650 | 2019 | AMERICA | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max XT DPS      | 854 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 850 EFI 4X4 Max XT-P DPS    | 854 | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 6x6 XT DPS         | 976 | 2019 | AMERICA | 61 KW(82 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max XT T DPS    | 570 | 2019 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 T XT DPS        | 650 | 2019 | EUROPE  | 46 KW(62 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT T DPS    | 650 | 2019 | EUROPE  | 43 KW(59 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 EFI 4X4 Max XT-P T DPS  | 650 | 2019 | EUROPE  | 43 KW(59 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 EFI 4X4 Max XT-P T DPS | 976 | 2019 | EUROPE  | 61 KW(82 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max XT DPS      | 570 | 2020 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 XT DPS          | 570 | 2020 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 570 EFI 4X4 Max XT T DPS    | 570 | 2020 | EUROPE  | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4               | 650 | 2009 | ALL     | 44 KW(60 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4               | 800 | 2009 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4               | 650 | 2010 | ALL     | 44 KW(60 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4               | 800 | 2010 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4               | 800 | 2011 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI                   | 800 | 2011 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI                   | 800 | 2012 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                             |      |      |         |               |                               |                 |
|--------------|-----------------------------|------|------|---------|---------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4     | 800  | 2012 | AMERICA | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI         | 800  | 2013 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4     | 800  | 2013 | AMERICA | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4     | 1000 | 2013 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI         | 800  | 2014 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4     | 800  | 2014 | AMERICA | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4     | 1000 | 2014 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4     | 800  | 2015 | ALL     |               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI         | 800  | 2015 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4     | 1000 | 2015 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4     | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI         | 800  | 2016 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI         | 800  | 2017 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI         | 800  | 2018 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI         | 800  | 2019 | AMERICA | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 DPS | 800  | 2013 | AMERICA | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI DPS     | 800  | 2013 | AMERICA | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 DPS | 800  | 2014 | AMERICA | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI DPS     | 800  | 2014 | AMERICA | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 DPS | 800  | 2015 | ALL     |               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |



|              |                                      |      |      |         |               |                               |                 |
|--------------|--------------------------------------|------|------|---------|---------------|-------------------------------|-----------------|
| CAN AM (BRP) | COMMANDER 800 R EFI DPS              | 800  | 2015 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 DPS         | 1000 | 2016 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 DPS          | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI DPS              | 800  | 2016 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI DPS              | 800  | 2017 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 DPS          | 1000 | 2017 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 DPS         | 1000 | 2017 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI DPS             | 1000 | 2018 | ALL     | 63 KW(86 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI DPS              | 800  | 2018 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 DPS          | 1000 | 2018 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 DPS         | 1000 | 2018 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI DPS              | 800  | 2019 | AMERICA | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI DPS             | 1000 | 2019 | AMERICA | 68 KW(92 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 DPS         | 976  | 2019 | AMERICA | 67 KW(91 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Limited DPS | 1000 | 2016 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI Limited DPS     | 1000 | 2018 | ALL     | 63 KW(86 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI Limited DPS     | 1000 | 2019 | AMERICA | 68 KW(92 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 LTD          | 800  | 2010 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 Max          | 650  | 2009 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max          | 800  | 2009 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |  |      |      |         |               |                               |                 |
|--------------|--|------|------|---------|---------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max LTD          | 800  | 2009 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 Max              | 650  | 2010 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max              | 800  | 2010 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max LTD          | 800  | 2010 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max              | 800  | 2011 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max LTD          | 800  | 2011 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max LTD          | 800  | 2012 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max              | 800  | 2012 | AMERICA | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max DPS          | 800  | 2013 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max              | 1000 | 2013 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max DPS          | 800  | 2014 | ALL     | 53 KW(72 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max              | 1000 | 2014 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max DPS          | 800  | 2015 | ALL     |               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max              | 1000 | 2015 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max DPS          | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max Limited DPS | 1000 | 2016 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max Limited DPS | 1000 | 2017 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max DPS          | 1000 | 2018 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max Limited DPS | 1000 | 2018 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI Max DPS             | 1000 | 2018 | AMERICA | 63 KW(86 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |  |      |      |         |               |                               |                 |
|--------------|--|------|------|---------|---------------|-------------------------------|-----------------|
| CAN AM (BRP) | COMMANDER 1000 R EFI Max Limited DPS                   | 1000 | 2018 | AMERICA | 63 KW(86 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI Max DPS                            | 800  | 2019 | AMERICA | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI Max Limited DPS                   | 1000 | 2019 | AMERICA | 68 KW(92 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max Limited DPS               | 976  | 2019 | AMERICA | 67 KW(91 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI Mossy Oak Hunting Edition DPS     | 1000 | 2018 | ALL     | 63 KW(86 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Mossy Oak Hunting Edition DPS | 1000 | 2018 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Mossy Oak Hunting Edition DPS | 976  | 2019 | AMERICA | 67 KW(91 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 X MR                           | 800  | 2011 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 X MR                           | 800  | 2012 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X rs                           | 1000 | 2013 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max X rs                       | 1000 | 2013 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X rs                           | 1000 | 2014 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X MR                           | 1000 | 2014 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X rs DPS                       | 1000 | 2014 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max X rs DPS                   | 1000 | 2014 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X ds DPS                       | 1000 | 2015 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 X MR DPS                       | 800  | 2015 | ALL     |               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X rs DPS                       | 1000 | 2015 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X MR DPS                       | 1000 | 2015 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max X rs DPS                   | 1000 | 2015 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                      |      |      |         |               |                               |                 |
|--------------|--------------------------------------|------|------|---------|---------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 X MR DPS    | 1000 | 2016 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X MR DPS     | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X ds DPS     | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max X rs DPS | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X MR DPS     | 1000 | 2017 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max X MR DPS | 1000 | 2017 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 X MR DPS    | 1000 | 2017 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X MR DPS     | 1000 | 2018 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 Max X MR DPS | 1000 | 2018 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 X MR DPS    | 1000 | 2018 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 X MR DPS    | 976  | 2019 | AMERICA | 67 KW(91 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 X XC         | 800  | 2011 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X XC DPS     | 1000 | 2014 | AMERICA | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X XC DPS     | 1000 | 2015 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 XC           | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 XC DPS       | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X XC DPS     | 1000 | 2016 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 XC DPS       | 1000 | 2017 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 XC           | 1000 | 2017 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X XC DPS     | 1000 | 2017 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                   |      |      |         |               |                               |                 |
|--------------|-----------------------------------|------|------|---------|---------------|-------------------------------|-----------------|
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 XC        | 1000 | 2018 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 XC DPS    | 1000 | 2018 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | MAVERICK 1000 R EFI 4X4 X XC DPS  | 1000 | 2018 | ALL     | 75 KW(102 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 X XC DPS | 1000 | 2018 | ALL     | 66 KW(90 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 X XC DPS | 976  | 2019 | AMERICA | 67 KW(91 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 XT        | 650  | 2009 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 Max XT    | 650  | 2009 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT        | 800  | 2009 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT    | 800  | 2009 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 XT        | 650  | 2010 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 XT-R      | 650  | 2010 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 Max XT    | 650  | 2010 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 650 R EFI 4X4 Max XT-R  | 650  | 2010 | ALL     | 44 KW(60 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT        | 800  | 2010 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT-R      | 800  | 2010 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT    | 800  | 2010 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT-R  | 800  | 2010 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT        | 800  | 2011 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT-P      | 800  | 2011 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT    | 800  | 2011 | ALL     | 52 KW(71 PS)  | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                      |     |      |         |              |                               |                 |
|--------------|--------------------------------------|-----|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT-P     | 800 | 2011 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT               | 800 | 2011 | AMERICA | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT           | 800 | 2012 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT       | 800 | 2012 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT-P     | 800 | 2012 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT               | 800 | 2012 | AMERICA | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT DPS       | 800 | 2013 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT-P DPS | 800 | 2013 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT-P DPS     | 800 | 2013 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT DPS   | 800 | 2013 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT DPS           | 800 | 2013 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT DPS       | 800 | 2014 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT-P DPS | 800 | 2014 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT-P DPS     | 800 | 2014 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT DPS   | 800 | 2014 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT DPS           | 800 | 2014 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT DPS       | 800 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 XT-P DPS     | 800 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT DPS   | 800 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 800 R EFI 4X4 Max XT-P DPS | 800 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                       |      |      |         |              |                               |                 |
|--------------|---------------------------------------|------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | COMMANDER 800 R EFI XT DPS            | 800  | 2015 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT DPS       | 1000 | 2016 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT-P DPS     | 1000 | 2016 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT DPS            | 800  | 2016 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max XT DPS   | 1000 | 2016 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max XT-P DPS | 1000 | 2016 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT DPS            | 800  | 2017 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT DPS       | 1000 | 2017 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT-P DPS     | 1000 | 2017 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max XT DPS   | 1000 | 2017 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max XT-P DPS | 1000 | 2017 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI XT DPS           | 1000 | 2018 | ALL     | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT DPS            | 800  | 2018 | ALL     | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT DPS       | 1000 | 2018 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max XT DPS   | 1000 | 2018 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT-P DPS     | 1000 | 2018 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI Max XT DPS       | 1000 | 2018 | AMERICA | 63 KW(86 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 800 R EFI XT DPS            | 800  | 2019 | AMERICA | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI XT DPS           | 1000 | 2019 | AMERICA | 68 KW(92 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | COMMANDER 1000 R EFI Max XT DPS       | 1000 | 2019 | AMERICA | 68 KW(92 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                       |      |      |         |                            |                               |                 |
|--------------|---------------------------------------|------|------|---------|----------------------------|-------------------------------|-----------------|
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT DPS       | 976  | 2019 | AMERICA | 67 KW(91 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 XT-P DPS     | 976  | 2019 | AMERICA | 67 KW(91 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max XT DPS   | 976  | 2019 | AMERICA | 67 KW(91 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | OUTLANDER 1000 R EFI 4X4 Max XT-P DPS | 976  | 2019 | AMERICA | 67 KW(91 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 EFI HO 4X4               | 800  | 2007 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 500 EFI HO 4X4               | 500  | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 EFI HO 4X4               | 800  | 2008 | ALL     |                            | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 500 EFI 4X4                  | 500  | 2009 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4                | 800  | 2009 | ALL     | 52 KW(71 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 500 EFI 4X4                  | 500  | 2010 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4                | 800  | 2010 | ALL     | 52 KW(71 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 500 EFI 4X4                  | 500  | 2011 | ALL     | 30 KW(41 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4                | 800  | 2011 | ALL     | 52 KW(71 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4                | 800  | 2012 | ALL     | 15 KW(20 PS); 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 500 EFI 4X4                  | 500  | 2012 | ALL     | 15 KW(20 PS); 30 KW(41 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4                 | 1000 | 2012 | AMERICA | 61 KW(83 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4                | 800  | 2013 | ALL     | 53 KW(72 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 500 EFI 4X4                  | 500  | 2013 | ALL     | 35 KW(47 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4                 | 1000 | 2013 | AMERICA | 61 KW(83 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4                | 800  | 2014 | ALL     | 53 KW(72 PS)               | Must use ITP Lug nut ALUG14BX | Left Front/Rear |



|              |                                  |      |      |         |              |                               |                 |
|--------------|----------------------------------|------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | RENEGADE 500 EFI 4X4             | 500  | 2014 | ALL     | 35 KW(47 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4            | 1000 | 2014 | AMERICA | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4            | 1000 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4           | 800  | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 500 EFI 4X4             | 500  | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4             | 570  | 2016 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4             | 800  | 2016 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4          | 1000 | 2016 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4             | 800  | 2017 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4             | 570  | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4          | 1000 | 2017 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4             | 570  | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4             | 800  | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4          | 1000 | 2018 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4             | 570  | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4             | 854  | 2019 | AMERICA | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4          | 976  | 2019 | AMERICA | 67 KW(91 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 EFI HO 4X4 X        | 800  | 2008 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X MR DPS | 1000 | 2016 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4 X MR DPS    | 570  | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                  |      |      |         |              |                               |                 |
|--------------|----------------------------------|------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X MR DPS | 1000 | 2017 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4 X MR DPS    | 570  | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X MR DPS | 1000 | 2018 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X MR DPS | 976  | 2019 | ALL     | 67 KW(91 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4 X MR DPS    | 570  | 2019 | AMERICA | 35 KW(48 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4 X XC      | 800  | 2009 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4 X XC      | 800  | 2010 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4 X XC      | 800  | 2011 | ALL     | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4 X XC       | 1000 | 2012 | ALL     | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4 X XC      | 800  | 2012 | AMERICA | 52 KW(71 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4 X XC DPS   | 1000 | 2013 | ALL     | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4 X XC DPS  | 800  | 2013 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4 X XC DPS   | 1000 | 2014 | ALL     | 61 KW(83 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4 X XC DPS  | 800  | 2014 | AMERICA | 53 KW(72 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 EFI 4X4 X XC DPS   | 1000 | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 800 R EFI 4X4 X XC DPS  | 800  | 2015 | ALL     |              | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4 X XC DPS    | 800  | 2016 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X XC DPS | 1000 | 2016 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4 X XC DPS    | 800  | 2017 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X XC DPS | 1000 | 2017 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |

|              |                                    |      |      |         |              |                               |                 |
|--------------|------------------------------------|------|------|---------|--------------|-------------------------------|-----------------|
| CAN AM (BRP) | RENEGADE 570 EFI 4X4 X XC DPS      | 570  | 2017 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 570 EFI 4X4 X XC DPS      | 570  | 2018 | ALL     | 36 KW(49 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4 X XC DPS      | 800  | 2018 | ALL     | 58 KW(79 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X XC DPS   | 1000 | 2018 | ALL     | 66 KW(90 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 850 EFI 4X4 X XC DPS      | 854  | 2019 | ALL     | 57 KW(78 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X XC DPS   | 976  | 2019 | ALL     | 67 KW(91 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 650 EFI 4X4 X XC T DPS    | 650  | 2019 | EU-ROPE | 43 KW(59 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |
| CAN AM (BRP) | RENEGADE 1000 R EFI 4X4 X XC T DPS | 976  | 2019 | EU-ROPE | 67 KW(91 PS) | Must use ITP Lug nut ALUG14BX | Left Front/Rear |